

Applying A Large Vinyl Peice

1.) I should mention: if you used a latex paint, with soil or stain resistance additives in it after 1 week it will "resist" the adhesive and everything will curl up and fall off. Benjamin Moore is one of the brands with this additive. HOOKAY here we go... Line up the media vinyl here you want it on the board. Tape at Half way and on one end. This is so it won't swivel



2.) Roll back to 1/2 way point, and peel back the backing and crease it.



3.) Fold the entire thing flat again. Okay, okay, nearly flat



4.) Pul it tight,



5.) put yer finger 1/2 way 2" in from the end of the vinyl. Now, run yer finger from the centre to the outside edge Now, squeegee from the centre out.



6.) You still have about an inch not down at the edge, squeegee outwards



7.) Okay you've got one end on good so it can't swivel, so NOW remove yer tape pieces



8.) Pull the release liner back some, so that the vinyl does not lie on the board by itself, you want to squeegee it on, if it lies flat you will get wrinkles, and bubbles of air. Squeegee from the centre out, slowly pulling the backing back, with yer other hand. (I couldn't take this picture I was short one hand)



9.) Pull the backing off



10.) Last thing, Frog Juice the entire board. The vinyl will off-gas, so you will have to go back and forth over it with yer FOAM brush, until no bubbles are evident

